

THE USUAL SUSPECTS

ICONIC VIBRATOR COLLECTION

JIMMYJANE



ICONIC SMOOTHIE

AKA "SMOOTHIE VIBRATOR"

THE USUAL SUSPECTS are recognizable at a glance and have become mainstays of popular culture. Whether you're updating a personal favorite or trying something new, these familiar vibrators will round out any stash. To make it easy, we tracked down the best of each style, distilled them to pure white, and gather them into a single collection just for you.

Simple and to the point.

Smoothie Vibrators (or simply "Smoothies") first appeared on the market as far back as the 1940's, when they were among the first battery–powered vibrators available. They are typically simple cylindrical forms ending in a rounded tip, and varying in length, diameter and power to suit different desires. Originally offered under the guise of "personal massagers", these basic, but highly functional designs ushered in the era of cordless pleasure.

Today, the Smoothie Vibrator is perhaps the single most recognizable of THE USUAL SUSPECTS, and for many is the design that springs to mind when a vibrator is mentioned. With their elongated shape, Smoothies can be used for internal or external stimulation, and offer an inexpensive and unintimidating starting point for those new to sex accessories. The ICONIC SMOOTHIE is also waterproof, adding additional possibilities and making it a fun and easy introduction to the world of vibrators.

Sexy is smart.

Jimmyjane is a design–centric brand founded on the belief that life is better with a sexy twist. We design products and experiences to provide pleasure, strengthen connection and create provocative possibility.

Instructions for Use

We know you're eager to start playing with your ICONIC SMOOTHIE, but indulge us by taking a minute to learn about operating and maintaining it.

Getting Started

- Good news everything you need to get started is right here in this box.
- The vibrator uses 2 AA batteries (included). To install the batteries, unscrew the cap and insert them
 in the vibrator, noting the proper orientation as shown below [need to add image]. Close the cap
 tightly to ensure the product is waterproof.
- Twist the top of the cap clockwise to turn the ICONIC SMOOTHIE on. The intensity of the vibration will increase as you continue to twist.
- Twist the cap counter-clockwise to turn the vibrator off. Make sure the vibrator is turned all the way
 off when you are done, or the batteries may discharge.

Cleaning the ICONIC SMOOTHIE

Clean the vibrator with mild soap and water after each use. Remember, the cap must be securely closed to ensure the product is waterproof. Dry with a soft cloth.

Safety Notes

- Do not use a defective ICONIC SMOOTHIE (defective or cracked surface or corroded battery).
- The vibrator should be operated in water only when fully assembled in accordance with the instructions.

- Do not use vibrator on swollen or inflamed areas or broken skin.
- Do not use on unexplained calf pain.
- Do not leave unattended on any surface while it is operating.
- Never use the product while sleeping.
- Individuals with pacemakers or other implanted devices should consult a doctor before use.
- Do not use this product as a substitute for medical attention.
- Keep the vibrator and batteries out of reach of children and pets.

Limited Warranty and Restrictions

Jimmyjane warrants the ICONIC SMOOTHIE against defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, finishes, normal wear and tear, tampering, unreasonable use, service performed by unauthorized service agencies, or loss or damage to batteries or removable parts.

THE FOREGOING IS THE SOLE WARRANTY FOR THE PRODUCT. JIMMYJANE HEREBY DISCLAIMS ANY IMPLIED WARRANTY THAT THE PRODUCT WILL BE MERCHANDISEABLE OR FIT FOR ANY PARTICULAR PURPOSE. JIMMYJANE'S LIABILITY AND CUSTOMERS' EXCLUSIVE REMEDY UNDER THE FOREGOING PARAGRAPH WILL BE LIMITED TO REPLACEMENT OR REPAIR BY JIMMYJANE OF SUCH PRODUCT, IN JIMMYJANE'S SOLE DISCRETION. THE WARRANTIES ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

For additional information, contact us at customerservice@jimmyjane.com or visit WWW.JIMMYJANE.COM.



ICONIC BULLET

AKA "BULLET VIBRATOR"

THE USUAL SUSPECTS are recognizable at a glance and have become mainstays of popular culture. Whether you're updating a personal favorite or trying something new, these familiar vibrators will round out any stash. To make it easy, we tracked down the best of each style, distilled them to pure white, and gather them into a single collection just for you.

Mini, yet mighty.

Bullet Vibrators have been around since the 70's and first earned their name from their compact, capsule shape and bright, metallic finish. While we've left the chrome behind, the Bullet's unintimidating form and obvious ease–of–use remain, making these a very popular first–time vibrator.

Though small, the ICONIC BULLET is powerful and effective. A versatile companion, it adds zing anywhere your hand roams. A great travel companion, the ICONIC BULLET is discreet, waterproof and a welcome addition to any handbag, glove compartment, backpack or carry—on.

Sexy is smart.

Jimmyjane is a design—centric brand founded on the belief that life is better with a sexy twist. We design products and experiences to provide pleasure, strengthen connection and create provocative possibility.

Instructions for Use

We know you're eager to start playing with your ICONIC BULLET, but indulge us by taking a minute to learn about operating and maintaining it.

Getting Started

- Good news everything you need to get started is right here in this box.
- The vibrator uses 3 LR44 batteries (already installed). To use for the first time, unscrew the cap and remove the tag from the battery compartment. Close the cap tightly to ensure the product is waterproof.
- Push the button on top of the cap of the vibrator to turn the ICONIC BULLET on.
- There are 3 power levels. Each push of the button increases the power level until the 4th push of the button, which turns the vibrator off.

Cleaning the ICONIC BULLET

Clean the vibrator with mild soap and water after each use. Remember, the cap must be securely closed to ensure the product is waterproof. Dry with a soft cloth.

Safety Notes

- Do not use a defective ICONIC BULLET (defective or cracked surface or corroded battery).
- The vibrator should be operated in water only when fully assembled in accordance with the instructions.
- Do not use vibrator on swollen or inflamed areas or broken skin.
- Do not use on unexplained calf pain.
- Do not leave unattended on any surface while it is operating.
- Never use the product while sleeping.
- Individuals with pacemakers or other implanted devices should consult a doctor before use.
- Do not use this product as a substitute for medical attention.
- Keep the vibrator and batteries out of reach of children and pets.

Limited Warranty and Restrictions

Jimmyjane warrants the ICONIC BULLET against defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, finishes, normal wear and tear, tampering, unreasonable use, service performed by unauthorized service agencies, or loss or damage to batteries or removable parts.

THE FOREGOING IS THE SOLE WARRANTY FOR THE PRODUCT. JIMMYJANE HEREBY DISCLAIMS ANY IMPLIED WARRANTY THAT THE PRODUCT WILL BE MERCHANDISEABLE OR FIT FOR ANY PARTICULAR PURPOSE. JIMMYJANE'S LIABILITY AND CUSTOMERS' EXCLUSIVE REMEDY UNDER THE FOREGOING PARAGRAPH WILL BE LIMITED TO REPLACEMENT OR REPAIR BY JIMMYJANE OF SUCH PRODUCT, IN JIMMYJANE'S SOLE DISCRETION. THE WARRANTIES ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

For additional information, contact us at customerservice @jimmyjane.com or visit WWW.JIMMYJANE.COM.



ICONIC RING AKA "VIBRATING RING"

THE USUAL SUSPECTS are recognizable at a glance and have become mainstays of popular culture. Whether you're updating a personal favorite or trying something new, these familiar vibrators will round out any stash. To make it easy, we tracked down the best of each style, distilled them to pure white, and gather them into a single collection just for you.

Look ma. no hands!

Only recently introduced to the market, Vibrating Rings have immediately become a favorite. The first hands–free vibrators to become widely available, they're an easy way for couples to share sensation. Their innocuous appearance and compact size has enabled them to be carried by mainstream retailers who had previously hesitated to sell vibrators.

Unlike the disposable products that are most common on the market, the iconic ring features replaceable batteries for an extended life. It's also one of the most versatile products of its kind, featuring a unique touch–sensitive vibration mode and shower–friendly water resistance.

Embraced by many for their ease of use and no-nonsense design, Vibrating Rings are enjoyed by first-time vibrator users and experienced enthusiasts alike.

Sexy is smart.

Jimmyjane is a design—centric brand founded on the belief that life is better with a sexy twist. We design products and experiences to provide pleasure, strengthen connection and create provocative possibility.

Instructions for Use

We know you're eager to start playing with your ICONIC RING, but indulge us by taking a minute to learn about operating and maintaining it.

Getting Started

- The ICONIC RING has already been cleaned and is ready to go upon opening.
- The vibrator is always ready to operate in a touch–sensitive mode, and will be activated when
 pressure is applied to the textured side of the elastomer sleeve. For constant vibration, depress the
 button on the side of the vibrator.
- The vibrator is water-resistant and shower-friendly. Before using, check that the elastomer plug is properly positioned to ensure the vibrator is sealed.
- The ICONIC RING runs on two LR1130 batteries. To access the battery compartment, remove the plug from the bottom of the elastomer sleeve. The compartment can be opened with a coin.

Cleaning the ICONIC RING

Remove the vibrating unit from the elastomer sleeve and keep it dry. Clean the sleeve with mild soap and warm water. Dry it thoroughly with a soft, lint–free cloth before reassembling.

Safety Notes

- Do not use a defective ICONIC RING (e.g. defective surface or corroded battery).
- Do not submerge the vibrator in water.
- Do not use vibrator on swollen or inflamed areas or broken skin.
- Do not leave unattended on any surface while it is operating.
- Do not store with vinyl products.

- Do not use with petroleum jelly.
- Never use the product while sleeping.
- Individuals with pacemakers or other implanted devices should consult a doctor before use.
- Do not use this product as a substitute for medical attention.
- Keep the vibrator and batteries out of reach of children and pets.

Limited Warranty and Restrictions

Jimmyjane warrants the ICONIC RING against defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, finishes, normal wear and tear, tampering, unreasonable use, service performed by unauthorized service agencies, or loss or damage to batteries or removable parts.

THE FOREGOING IS THE SOLE WARRANTY FOR THE PRODUCT. JIMMYJANE HEREBY DISCLAIMS ANY IMPLIED WARRANTY THAT THE PRODUCT WILL BE MERCHANDISEABLE OR FIT FOR ANY PARTICULAR PURPOSE. JIMMYJANE'S LIABILITY AND CUSTOMERS' EXCLUSIVE REMEDY UNDER THE FOREGOING PARAGRAPH WILL BE LIMITED TO REPLACEMENT OR REPAIR BY JIMMYJANE OF SUCH PRODUCT, IN JIMMYJANE'S SOLE DISCRETION. THE WARRANTIES ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

For additional information, contact us at customerservice@jimmyjane.com or visit WWW.JIMMYJANE.COM.



ICONIC POCKET AKA "POCKET VIBRATOR"

THE USUAL SUSPECTS are recognizable at a glance and have become mainstays of popular culture. Whether you're updating a personal favorite or trying something new, these familiar vibrators will round out any stash. To make it easy, we tracked down the best of each style, distilled them to pure white, and gather them into a single collection just for you.

Pleasure to go.

Pocket Vibrators were first produced over 25 years ago. Their compact all—in—one design made them the most portable vibrators available at the time — other mini vibrators were wired to a separate battery pack, and were clumsy by comparison. Pocket Vibrators were also among the first waterproof vibrators in wide circulation, ensuring that they immediately made a splash.

While Pocket Vibrators were designed to be compact, they were also engineered to be powerful. The four hemispheres on the tip of the vibrator help intensify sensation by varying the contact pressure as they are moved across the body. For alternative sensations, Pocket Vibrators can also be used with the clear cap in place, or with one of the many soft elastomer accessory sleeves now widely available.

The versatility and innocuous appearance of the Pocket Vibrator, combined with its usefulness for non-sexual massage, has given everyone a reason – and an excuse – to keep one handy.

Sexy is smart.

Jimmyjane is a design—centric brand founded on the belief that life is better with a sexy twist. We design products and experiences to provide pleasure, strengthen connection and create provocative possibility.

Instructions for Use

We know you're eager to start playing with your ICONIC POCKET, but indulge us by taking a minute to learn about operating and maintaining it.

Getting Started

- The ICONIC POCKET has already been cleaned and is ready to go upon opening.
- The ICONIC POCKET is waterproof and ready to make a splash. Be sure that the battery compartment is completely closed before using in or near water.
- The vibrator uses 1 AA battery. To open the battery compartment, line up the downward pointing triangle with the line and pull gently.



Cleaning the ICONIC POCKET

After each use, clean the vibrator with mild soap and warm water. Remember that the battery case must be closed completely to ensure waterproofing. Dry with a soft cloth.

Safety Notes

- Do not use a defective ICONIC POCKET (e.g. defective or cracked surface or corroded battery).
- Do not use vibrator on swollen or inflamed areas or broken skin.
- Do not use on unexplained calf pain.
- Do not leave unattended on any surface while it is operating.
- Never use the product while sleeping.
- Individuals with pacemakers or other implanted devices should consult a doctor before use.
- Do not use this product as a substitute for medical attention.
- Keep the vibrator and batteries out of reach of children and pets.

Limited Warranty and Restrictions

Jimmyjane warrants the ICONIC POCKET against defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, finishes, normal wear and tear, tampering, unreasonable use, service performed by unauthorized service agencies, or loss or damage to batteries or removable parts.

THE FOREGOING IS THE SOLE WARRANTY FOR THE PRODUCT. JIMMYJANE HEREBY DISCLAIMS ANY IMPLIED WARRANTY THAT THE PRODUCT WILL BE MERCHANDISEABLE OR FIT FOR ANY PARTICULAR PURPOSE. JIMMYJANE'S LIABILITY AND CUSTOMERS' EXCLUSIVE REMEDY UNDER THE FOREGOING PARAGRAPH WILL BE LIMITED TO REPLACEMENT OR REPAIR BY JIMMYJANE OF SUCH PRODUCT, IN JIMMYJANE'S SOLE DISCRETION. THE WARRANTIES ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

For additional information, contact us at customerservice@jimmyjane.com or visit WWW.JIMMYJANE.COM.



ICONIC RABBIT

AKA "TWICE AS NICE"

THE USUAL SUSPECTS are recognizable at a glance and have become mainstays of popular culture. Whether you're updating a personal favorite or trying something new, these familiar vibrators will round out any stash. To make it easy, we tracked down the best of each style, distilled them to pure white, and gather them into a single collection just for you.

The rabbit that started it all.

Perhaps the best known vibrator ever made, this "Rabbit Habit" is the original that inspired hundreds of derivative products. Created in Japan over 25 years ago, it was the first to offer simultaneous internal and external stimulation. This configuration was so successful that it launched an entire category of products, now known in the industry as "Twice As Nice" vibrators.

The popularity of this design is telling. Conservative estimates indicate that over 5 million "Twice As Nice" vibrators are made each year, and production levels are still growing. Adding to the momentum, several celebrities have spoken openly of their affinity for the product. No stranger to the limelight, it has made appearances on numerous TV shows – most memorably, its cameo on Sex and the City in 1998.

The curious appearance of the vibrator is functionally derived, but culturally embellished. The Rabbit Habit features a stylized rabbit attached to the base of a shaft, which, upon closer examination, is detailed to resemble a woman, complete with a caricature face, necklace, and bob haircut. In Japan there is a long—standing taboo surrounding the depiction of genitalia. As a result, in sexual implements dating back millennia, faces and other details were often sculpted onto otherwise phallic forms to soften their visual impact and disguise (albeit only slightly) their functional intent. Some of the more elaborate designs even included swords, kimonos, and other details to represent samurai and geisha characters. Today, an entire menagerie of Twice As Nice vibrators is available, featuring animals ranging from dolphins to seahorses, monkeys to birds.

Sexy is smart.

Jimmyjane is a design—centric brand founded on the belief that life is better with a sexy twist. We design products and experiences to provide pleasure, strengthen connection and create provocative possibility.

Instructions for Use

We know you're eager to start playing with your ICONIC RABBIT, but indulge us by taking a minute to learn about operating and maintaining it.

Getting Started

- The ICONIC RABBIT has already been cleaned and is ready to go upon opening.
- The ICONIC RABBIT runs on 3 AA batteries. Slide the cover off the battery compartment to insert batteries. (Batteries included.)
- There are independent motors for both the shaft and the tickler, each offering variable speeds (high to low).
- The vibrator can be shaped to your liking. Hold the vibrator just beneath the pearls then gently bend the shaft. Do not bend at the pearls, and do not bend more than a few degrees.

Cleaning the ICONIC RABBIT

Clean the soft elastomer with a cloth and mild soap and warm water after each use, taking care not to get the battery pack wet. Pat dry with a soft, lint–free cloth.

Safety Notes

- Do not use a defective ICONIC RABBIT (e.g. defective surface or corroded battery).
- Do not get the battery pack wet.
- Do not bend the vibrator at the pearls.
- Do not use vibrator on swollen and inflamed areas or broken skin.
- Do not leave unattended on any surface while operating.
- Do not store with vinyl products.
- Do not use with petroleum jelly.
- Do not use the vibrator for more than 20 minutes at a time.
- Never use the product while sleeping.
- Individuals with pacemakers or other implanted devices should consult a doctor before use.
- Do no use this product as a substitute medical attention.
- Keep the vibrator and batteries out of reach of children and pets.

Limited Warranty and Restrictions

Jimmyjane warrants the ICONIC RABBIT against defects in materials and workmanship for a period of one (1) year from the date of purchase. This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, finishes, normal wear and tear, tampering, unreasonable use, service performed by unauthorized service agencies, or loss or damage to batteries or removable parts.

THE FOREGOING IS THE SOLE WARRANTY FOR THE PRODUCT. JIMMYJANE HEREBY DISCLAIMS ANY IMPLIED WARRANTY THAT THE PRODUCT WILL BE MERCHANDISEABLE OR FIT FOR ANY PARTICULAR PURPOSE. JIMMYJANE'S LIABILITY AND CUSTOMERS' EXCLUSIVE REMEDY UNDER THE FOREGOING PARAGRAPH WILL BE LIMITED TO REPLACEMENT OR REPAIR BY JIMMYJANE OF SUCH PRODUCT, IN JIMMYJANE'S SOLE DISCRETION. THE WARRANTIES ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

For additional information, contact us at customerservice@jimmyjane.com or visit WWW.JIMMYJANE.COM.