


Thrill

BY
WE VIBE™

User Manual



Control handle for perfect positioning

Clitoral vibrator for intense stimulation

Anatomically designed G-Spot stimulator



One-button pleasure control

Dual stimulation designed for the ultimate sensation

The Thrill by We-Vibe™ is a waterproof, rechargeable vibrator that is scientifically designed to help women experience complete pleasure. The ergonomic shape works in sync with a woman's body, providing intense stimulation for her G-Spot and clitoris. With the touch of a single button, she enjoys maximum stimulation, comfort and control.

SIMPLY CHARGE AND ENJOY

- Charge your Thrill by We-Vibe as shown.
- If desired, lubricate your Thrill by We-Vibe with water-based lubricant or an approved silicone-based lubricant¹.
- Gently insert your Thrill by We-Vibe as shown.
- To turn on, press the control button.
- To change the vibration mode, press and release the control button.
- To turn off, hold the control button down for 2 seconds or press it repeatedly to move through the vibration modes until you reach the off position.



8 THRILLING VIBRATION MODES

1	LOW (3000 RPM)	VIBE	5		TEASE
2	MEDIUM (3600 RPM)	VIBE	6		WAVE
3	HIGH (4200 RPM)	VIBE	7		PULSE
4	ULTRA (4800 RPM)	VIBE	8		CHA-CHA

CHARGING AND BATTERY LIFE

- You can use any USB power adapter with your Thrill by We-Vibe. USB power adapters are commonly available, so in the interest of conservation, a power adapter is not included with this product.
- A full charge takes up to 90 minutes.
- A full charge will last up to 2 hours, depending on the vibration mode. Modes with higher vibration speeds will drain the battery faster.
- There's no need to drain the battery before recharging as the charging system automatically shuts off when full charge is reached.
- Charge is maintained for several months, but will continually diminish over time. For best performance, recharge regularly.

CLEANING AND STORAGE

- Clean with soap and water after every use.
- Keep away from extreme heat or cold.
- Store in the original packaging, the fabric bag provided or on a clean surface so your Thrill by We-Vibe is ready when you are.

DO NOT

- Do not use your Thrill by We-Vibe with non-approved silicone-based lubricants as they will damage the product. For a list of approved lubricants, go to we-vibe.com/lubes.
- Do not boil, bake, microwave or put in a dishwasher.
- Do not store in extreme temperatures.

TROUBLESHOOTING

My Thrill by We-Vibe won't turn on

- Make sure it is charged. Note that the Thrill by We-Vibe will not charge in extreme heat or cold.
- Confirm that the USB cable is properly connected to both the charging base and an active USB power source.

My Thrill by We-Vibe won't charge

- Clean the charging contacts on both the Thrill by We-Vibe and the charging base with rubbing alcohol.
- Try using the USB cable from one of your other electronic devices.
- Try using a different USB power adapter.

My Thrill by We-Vibe won't turn off

- Hold the control button down for 2 seconds or cycle through the vibration modes until you reach the off position.

My charging base, USB cable or USB power adapter is lost or broken

- You can use other vendors' USB cables and any commercially available USB power adapter with your Thrill by We-Vibe. However, the Thrill by We-Vibe USB cable is custom-designed and intended only for use with We-Vibe products.
- Customers in the U.S. and Canada can purchase a replacement Thrill by We-Vibe charging base at we-vibe.com/replacement-charger. Customers in other countries can contact us as described below.

I need more help

- Go to we-vibe.com and review the frequently asked questions (FAQs) for the Thrill by We-Vibe.
- E-mail us at customer-service@we-vibe.com or complete the web form at we-vibe.com/contact-us-customer-service.

WARRANTY – ENGLISH

The one-year warranty covers defective product replacement only. Visit we-vibe.com/warranty for product return information. No other warranties are expressed or implied. If there is a warranty claim, or any other damage, the user's sole remedy is product replacement. No medical claims are implied or warranted by use of this product.

COMPLIANCE

This class B digital apparatus complies with Canadian ICES-003.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product has required the extraction and use of natural resources for its production. Improper disposal of this product could impact the environment and our health as it may contain hazardous substances. In order to avoid the dissemination of those substances in our environment and to diminish the pressure on the natural resources, we encourage you to use the appropriate take-back systems. Those systems will reuse or recycle most materials of your end-life equipment in a sound way. The crossed-out wheeled-bin symbol invites you to use those systems. For more information on the collection, reuse and recycling systems, please contact your local or regional waste administration. Contact us for more information on the environmental performance of our products.

For further compliance information, visit we-vibe.com.

WARNING

Sold as an adult novelty only; not for medical use and not clinically tested. This appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities. To avoid electric shock, do not use charger near water. Do not use on swollen or inflamed areas of skin. Discontinue use if discomfort occurs. Do not use on neck area. Do not use on a single area for more than 15 minutes.



Copyright 2012

Designed and Developed by Standard Innovation Corporation, Canada.



we-vibe.com